



FIRMWARE UPDATE MANUAL

SRP-GT

SRP-GTI

SRP-F1

- Download the firmware and software from the following link


<https://www.dropbox.com/t/zWtL09mgvvf3XTqY>

-Once downloaded, find out the COM port that uses the pedals by following this route.

Control panel / devices and printers /

Open SRP-GT/GT1/F1


Select the hardware tab and on the last line tell us which (COM) port you are using.



-In this example we have the port (COM 3)


-Run XLoader that is in the downloaded folder.

Select the .hex file from the download folder.




-Deploy the list of COM posts.


Depending on the equipment connected to your PC, you can have several, write down the list of ports if you have many, in my case I only have one port.



-Select the port of our assigned and press Upload, the following message will appear (Upload failed)




-We open the list of ports again and we will see that a new port appears.



-Select the new port and press upload again, after uploading the files the following message will appear * "18056 bytes uploaded" confirming that the firmware has been successfully updated.

* Uploaded bytes may vary depending on the firmware version.



-We close the XLoader application and can now open the SRP-MS application

Any questions please contact by mail to support@simracing-pro.com